


POCHETTE SWITCH



SIZES IN CM

COD.	W	H
10010	6	7
10011	9	10

SIZES IN INCHES

W	H
2.3	2.7
3.5	3.9